



Double Offset Tub Supplies by Randolph Morris

Item #: RM1309D

This bathroom fixture has been carefully engineered to provide a long, trouble-free service life under normal usage. It has been factory-tested and is ready for installation. We suggest this fixture be installed by a qualified licensed plumber so the warranty will remain in affect (refer to the "General Information" insert for warranty information). We also strongly recommend tub & hardware be on site prior to rough in.

- Shut off the water supply before installation.
- Use Teflon tape on all threaded connections.

Bath Supply Lines

- Measure the height from the floor to the center of the faucet nipple where the water supply tubes are to be connected. Cut the bottom side of the supply tubes (D & E) to the height needed for connection.
Note: Do not cut the top side of the supply tubes (D & E) to fit closer to the tub wall. There is a special crimp put on the tube for holding the tube secure to the back faucet. Cutting the crimp off will result in water damage by water pressure blowing the tubes out of the locking slipnut and voids warranty.
- Place the following on the two supply tubes (D & E) as follows: At top of each tube on crimped end; place the brass friction washer on first (B). Then place the rubber cone washer on second (A) (beveled end facing toward the faucet nipple).
- Slide on from the bottom side of tube, the 3/4"-14 slipnut (C) Female end first for connecting to the faucet nipple.

Floor Connection

To make the bottom connection **without shut off valve:**

- First place the 1/2" OD Bell Flange (F) up the bottom side of the supply tubes.
- Slide on the 1/2"-14 slipnut (G) female end toward floor for water supply connection.
- Then add the 1/2" ID "O" ring (H) on last.