



Extended Lift & Turn Tub Drain by Randolph Morris

Item #: RM1900LTB

This bathroom fixture has been carefully engineered to provide a long, trouble-free service life under normal usage. It has been factory-tested and is ready for installation. We suggest this fixture be installed by a qualified licensed plumber so the warranty will remain in affect (refer to the "General Information" insert for warranty information). We also strongly recommend tub & hardware be on site prior to rough in.

- This drain is designed to fit new clawfoot tubs.
- Install shoe assembly (K) with rubber washer (L) to tub drain with lift & turn strainer (M).
A small amount of plumbers putty or bead of silicone should be used under the strainer.
- Install overflow assembly (A) with beveled washer (P), overflow plate (O) and oval head screw (N).
- Attach waste and overflow tee (D) to bath overflow assembly (A) and shoe assembly (K) with poly washers (E & I) and slip nuts (F & J).
- Assemble drain tube (G) with flange (H) to tee with poly washer (E) and slip nut (F).
- Run water in tub to check for any leak.

Note: For this 1-1/2" Waste & Overflow; the bottom "T" tube (G) is threaded and will fit the thread on tee.