



Deck Mount British Telephone Tub Faucet with Handshower by Randolph Morris

Item #: RMC627

This bathroom fixture has been carefully engineered to provide a long, trouble-free service life under normal usage. It has been factory-tested and is ready for installation. We suggest this fixture be installed by a qualified licensed plumber so the warranty will remain in affect (refer to the "General Information" insert for warranty information). We also strongly recommend tub & hardware be on site prior to rough in.

- Shut off the water supply valves before installation
- Please use Teflon tape on all threaded connections available at your local hardware or plumbing supply.
- Installations can vary depending on how previous fixtures were installed. Necessary supplies to install your faucet are not all included; however, they are available wherever plumbing supplies are sold.
- Connect the shorter threaded end of nipples (part # T500) to the deck mount couplers (part # RMC202). Insert the faucet through the 2 holes in the tub. Screw the locknuts onto the threaded nipples & tighten.
- Thread the deck mount couplers (part #RMC202) onto the modified swing arms (part # RMC300).
- Tighten the nuts of the deck mount couplers to the faucet body.
- The supply lines get inserted into the hook up nipples/shanks & tighten the supply nuts.
- Place the washer inside the nut at the bottom of the hand shower cradle and connect the cradle to the faucet & tighten.
- Attach the hand shower hose to the outlet of the hand shower cradle and to the hand shower. Place the hand shower on the cradle. If anti-syphon valve is used, it will be inserted between the cradle and the hose. (not included)