



WHITEHAUS COLLECTION<sup>®</sup>

*A Collection of Fine Products*

[www.whitehauscollection.com](http://www.whitehauscollection.com)

WHUMSB undermount support bars install just like closet poles, horizontally under the sink. The escutcheon pieces screw directly into the cabinetry. Slide the bar into the round escutcheon, then drop the bar into the cupped escutcheon.

A few tips:

Do not use a level on the bars! As the sinks are hand finished, they may not be exactly level themselves. Put one screw into each escutcheon to hold it in place, then put the sink onto the bars to check the height and level of the sink. Remove the sink and move the escutcheons accordingly. The sink will ideally be flat and level with the top of the cabinetry. Once the escutcheons are properly placed, put in the rest of the screws and place the sink on top of the bars.

Should you have any questions do not hesitate to contact our technical department at (800) 527-6690.