



CORNER BASIN INSTALLATION INSTRUCTIONS

Tools you will need: Level
Pencil
Screwdriver
Electric drill and appropriate drill bits
Adjustable wrench
2 molly bolts or toggle bolts or large wood screws
depending on wall (not included)
(optional) plumbers basin wrench to secure faucet

1. Determine height you want. Place sink in the corner. Use a level to make sure both sides are level.
2. Position each metal mounting bracket against the underside rear of bowl and against the wall. Mark location of mounting bracket holes on the wall.
3. Remove the bowl from the wall.
4. Start to drill hole in wall to accept molly bolts or toggle bolts. If drill bit hits a stud, mount brackets/bolts using large wood screws.
5. If molly bolts are used, install and expand the bolt holders, then mount brackets.
6. If toggle bolts are used, make holes large enough to accept collapsible wing nut bolt, then mount brackets.
7. Before replacing bowl, mount the faucet according to the manufacturer's instructions.
8. Hang bowl on wall brackets and check that it is level.
9. Connect all supply tubes to the faucet. Connect trap and drain assembly as described by the manufacturer.