

# General Minispread & Centerset Faucet Installation Instructions

**Please Note:** We are providing general guidelines for a standard installation as we cannot account for the individuality of the site or items you may be working with. This installation guide can be used as a general guide for most centerset and minispread faucets.

Tools Layout:

1. The most important tool to use when installing a pedestal sink and faucet is a licensed plumber. Most manufacturers will not accept warranty claims on items not installed by a licensed plumber.
2. [Adjustable wrench](#)



3. [Basin wrench](#)



4. [Curved-jaw channel locks \(pliers\)](#)



5. [Plumber's putty](#)



6. [Tape Measurer](#)

Instructions:

1. Screw the escutcheons onto the faucet nipples.



2. Place ¼" bead of plumber's putty on the bottom of both escutcheons. This will create a seal between the faucet and the sink.



3. Place the faucet on the sink.



4. Attach the faucet nuts.



5. Center the faucet.



6. With a basin wrench you will tighten the faucet lock nuts.



7. Remove the excess plumber's putty.



8. Place plumber's putty on the chain stay and insert the chain stay in the hole.





9. Place the metal break and screw the lock nut onto the chain stay screw with an adjustable wrench.

