

## General Showerhead Installation Instructions

**Please Note:** We are providing general guidelines for a standard installation as we cannot account for the individuality of the site or items you may be working with.

1. Use thread sealant or Teflon tape on the threaded area of the riser pipe.



2. Screw on the shower head and hand tighten.

