

## General Wall Mounted Telephone Faucet Installation Instructions

**Please Note:** We are providing general guidelines for a standard installation as we cannot account for the individuality of the site or items you may be working with.

Tools Layout:

1. The most important tool to use when installing a shower enclosure is a licensed plumber. Most manufacturers will not accept warranty claims on items not installed by a licensed plumber.
2. [Strap wrench](#)



3. [1/2" Tubing cutter](#)



4. [Smooth jawed pipe wrench](#)



5. [Straight-Jaw Channel Locks \(Pliers\)](#)



6. [Level](#)



7. [Power Drill](#)



8. [Thread Sealant](#) (Teflon tape or liquid form).

9. [Screwdriver](#)

10. [Hammer](#)

11. [Tape Measurer](#)

Instructions:

1. Apply a liberal amount of thread sealant to the short end of the faucet nipple. (Use teflon tape instead of thread sealant if the finish is supercoated brass).



2. Tighten the faucet nipple to the 1/2" thread on the faucet swing arm. You want to hand tighten a 1/4 turn using the strap wrench.



3. Repeat on the opposite side.

4. Take the faucet swing arm and place it in front of the faucet hole.



5. Apply the jam nut / lockdown nut to the back of the faucet nipple. (Do not tighten yet).



6. Repeat on the opposite side.



7. To attach the faucet body to the swing arms you will need to take the lock nut washer and install in the lock nut.



8. Tighten the lock nut to the faucet.



9. Repeat on the opposite side.

10. Apply the strap wrench to the lock nut and then hand tighten a 1/4 turn.



11. Use your sight to center the faucet the best you can.

12. Use the smooth jawed pipe wrench to tighten the jam nuts on the back of the tub. (Be careful not to over tighten to prevent cracking of the porcelain).



13. To attach the handshower holder, attach the washer to the lock nut.



14. Attach the lock nut to the faucet body.





15. Use the smooth jawed pipe wrench to tighten lock nut. Turn until tight.



16. Attach the shower hose lock nut to the arm.



17. Use the strap wrench to tighten the hose lock nut.



18. Place handshower on the holder.

