



# Alcove Tub Installation Guide

## **Before You Start:**

Carefully unpack and inspect all items for damages and ensure that the required parts were shipped complete. If you find damaged parts do not install contact Customer Service immediately.

We recommend using a professional plumbing installer if you are unfamiliar with vintage style bathroom fixtures and plumbing. Vintage Tub will not be responsible for any damage to the floor, walls, plumbing, or personal injury during installation. Please review all local plumbing and building codes to be sure your purchase is code compliant for your area.

*Note:* Due to the manufacturing process each tub will vary slightly dimensionally.

## **TUB INSTALLATION:**

1. Position the tub into the pre-constructed opening, plumb and level with plastic shims as required. Mark the finale position of the tub and wood support stringer locations onto the wood studs.

To locate the new drain line rough-in, set the tub in the fitted location with the overflow drain connection installed. Drop a plumb line from the centerline of the overflow outlet down to the drain location and mark out the centerline on the floor. This will determine your drain line rough-in location.

2. Remove the tub and attached the 2"x 4" wood stringer supports level onto the wood studs and install rough plumbing.
3. Onto the finished floor carefully set in place the tub in its finale position. Install the drain to the tub (not included).
4. Complete the tub installation by applying a bead of silicone sealant around the walls and base of the tub where it meets the finished floor. Wipe away all excess sealant with a damp cloth.

## **CAUTION:**

**Handle All Parts With Care**

**Read All Instruction Before Installing**

**Properly Test All Water Connections**

**All Local Plumbing Codes Apply**

**Confirm The Pipe Roughing Is In The Proper Location**

**No Soldering Or Heat Is Required For This Products Installation**

**Do Not Over Tighten Pipe Connections**