



# Cast Iron Wall Hung Farmhouse Sink Installation Instructions

1. Properly locate and level the mounting bracket(s) onto the finished wall and mark out all bolting holes at each mounting location.

**NOTE: THE SINK BRACKET(S) IS TO BE ANCHORED ONTO A MINIMUM SIZE 2"X 4" WOOD NAILER INSTALLED AT THE DESIRED HEIGHT BEHIND THE FINISHED WALL LOCATED IN BETWEEN EXISTING VERTICAL STUDS AS REQUIRED.**

2. Level and attach the mounting bracket(s) onto the finished wall using lag bolts to secure into the wood nailer at the desired elevation.
3. Prior to permanently mounting the sink onto the wall bracket(s) it is recommended to first install the new faucet, and new pop-up drain assembly onto the sink according to their installation instructions.
4. Lower the back of the sink onto the wall mounting bracket(s) while lining up all the sink hanging clips. Firmly push the sink downward onto the bracket until tight against the wall.

**NOTE: SOME WALL MOUNTED SINKS INCLUDE A PROTECTIVE TRIM PIECE TO COVER THE PLUMBING LINES. THESE TYPICALLY ATTACH DIRECTLY TO THE WALL FRAMING WITH LAG BOLTS.**

5. Connect the hot & cold water supply lines (not included) to the faucet as recommended.
6. Connect the drain p-trap and associated piping (not included) onto the pop-up drain assembly tail piece as recommended.
7. Separately and slowly open the hot and then the cold water supply lines checking all pipe connections for leaks.
8. While filling the sink basin run water through the drain piping checking all pipe connections for leaks.

**PLEASE CONSULT A LICENSED PLUMBER IF YOU ARE UNFAMILIAR WITH THIS TYPE OF INSTALLATION.  
IT IS RECOMMENDED THAT A LICENSED PLUMBING CONTRACTOR INSTALL THIS ITEM TO MAINTAIN WARRANTY.**