



## Wall Mount British Telephone Tub Faucet with Handshower by Randolph Morris

Item #: RMC146

This bathroom fixture has been carefully engineered to provide a long, trouble-free service life under normal usage. It has been factory-tested and is ready for installation. We suggest this fixture be installed by a qualified licensed plumber so the warranty will remain in affect (refer to the "General Information" insert for warranty information). We also strongly recommend tub & hardware be on site prior to rough in.

- Shut off the water supply valves before installation
- Please use Teflon tape on all threaded connections available at your local hardware or plumbing supply.
- Installations can vary depending on how previous fixtures were installed. Necessary supplies to install your faucet are not all included; however, they are available wherever plumbing supplies are sold.
- Loosen the nuts to make the swing arms adjustable and connect the shorter threaded end of the nipples (part # T7550) to the adjustable swing arms (part # RMC100). Insert the faucet through the 2 holes in the tub. Screw the locknuts onto the threaded nipples & tighten.
- Tighten the nuts of the swing arm couplers to the faucet body.
- The supply lines get inserted into the nipples/shanks & tighten the supply nuts connecting to the threaded 3/4" IPS end of the nipples/shanks.
- Place the washer inside the nut at the bottom of the hand shower cradle and connect the cradle to the faucet & tighten.
- Attach the hand shower hose to the outlet of the hand shower cradle and to the hand shower. Place the hand shower on the cradle. If anti-syphon valve is used, it will be inserted between the cradle and the hose.