

Clawfoot Tub Drain Installation Guide

BATHWASTE AND OVERFLOW INSTALLATION GUIDE

Note: Because the tubs vary in size, measure your space thoroughly before installation. Trim pipe accordingly to ensure a correct fit.

INSTALLATION STEP

- A. Seal the overflow drain pipe (7)(8) first, mount it to back side of tub wall. Use the thick washer (10) to prevent any water leakage.
*Certain style the pipe and elbow is pre-glued, no need to seal it. Hand loose and check first.
- B. Fasten the grid (11) to inside wall of the tub by lining the hole up with the threads and screw down till tight.
- C. Slide the lock nut (2) and washer (3) onto overflow drain pipe, connect it with drain body (5).
- D. Seal the bottom drain pipe (6)(9), slide the nut and washer onto it and connect with drain body. Line up the drain piece with the drain hole in the tub. Do the same for bottom tail piece (4).
- E. Depends on the waste style,
*** **LIFT & TURN STYLE** ***
Loosen screw from side of lift plug (15), install the drain grid (14) with gasket (13) through the top of the drain hole, screw down until tight. Reinstall the lift plug, line the screw hole up with the flat side of the stem sticking up from the drain, and tighten the screw in all the way.
*** **POP UP STYLE** ***
Loosen drain cap and pop up mechanism (15), install the drain grid (14) with gasket (13) through the top of the drain hole, screw down until tight. Reinstall the drain cap and pop up mechanism.
*** **PLUG STYLE** ***
Install the drain grid (14) with gasket (13) through the top of the drain hole, screw down until tight. Use assembled screw on overflow grid.
- F. After all components are installed place the base flange (1) over the bottom tail pipe before connecting to the waste plumb line. Connect the waste and overflow to plumb lines in the floor. Check for any leakage in the assembly.

