



Randolph Morris

# Exposed Shower Installation Guide

## EXPOSED PIPE SHOWER INSTALLATION GUIDE

### BEFORE YOU BEGIN \*\* IMPORTANT \*\*

Before installing, read entire installation instruction. Observe all local building and safety codes.

For the following installation instructions it is assumed that the water supply lines have been installed in the desired location behind the finished wall and are accessible for shower installation.

We recommend consulting a professional if you are unfamiliar with installing bathroom fixtures.

### INSTALLATION STEP

1. Assemble the shower riser as drawing, to use Teflon tape on pipe threads.
2. Assemble the loop, wall support tube and wall flange together. If necessary to cut the extra length of tube.
3. Attach the support to shower riser and screw the flange on wall.
4. Attach the hand shower cradle to shower riser.
5. Place Teflon tape on the 1/2" pipe thread in the shower wall and thread on the faucet couplers. Allow tape to cure for 24 hours before use.
6. Attach the faucet body to the couplers. Using faucet top connect nut and cone seal to connect the shower riser and faucet. Install the faucet handles.
7. Place Teflon tape on the thread of shower riser. Attach the shower head to the top of the riser with wrench.
8. To install a hand-held shower. Using included wall mount bracket to install on desire location. Attach the hand-held shower holder on bracket and screw it with set screw from bottom.
9. Attach the shower hose to faucet body with rubber washer.
10. Turn on the water supply and open the faucet valves. Check for any leaks. If leakage occurs, tighten connections again as necessary. Let the water flow through the shower hose for approximately 30 seconds to clear out debris and dirt.
11. Connect the hand-held shower with shower hose and check leaks.

### COMPLETE INSTALLATION

Note: All connections nuts, do not tighten more than 1/4 turn beyond hand tight.

