



Contemporary Double Post Freestanding Faucet Installation Guide

SKU: RMNCFSDP

This bathroom fixture has been carefully engineered to provide a long, trouble-free service life under normal usage. It has been factory-tested and is ready for installation. We suggest this fixture be installed by a qualified licensed plumber so the warranty will remain in affect (refer to the "General Information" section for warranty information). We also strongly recommend tub & hardware be on site prior to rough in.

- Shut off the water supply before installation.
 - Use Teflon tape on all threaded connections.
1. Lay the faucet down flat so that all parts can be easily viewed and accessed during assembly.
 2. Connect Supply Line Housing Tubes to the faucet body.
 3. Slide Shower holder over the Supply Line Housing Tubes of your choice. Secure with set screws.
 4. Slide the decorative Trim Flange over the Supply Line Housing Tube. Open end toward the bottom.
 5. Screw on the Mounting plate to Supply Line Housing Tube.
 6. Place mounting plate in desired location and install plastic anchor bolt sleeves into floor. Do not install screw at this time.
 7. Attached supply tubes to house supply lines.
 8. Using the Screws attach the mounting plate to the floor where you have installed your plastic anchor bolt sleeves.
 9. Slide Decorator trim flange down to cover brass mounting plate.
 10. Slide spout into the faucet body securing it with the set screw. Spout should not be rotated.
 11. Attach hand shower hose to the outlet on the bottom of the faucet body and to the hand shower wand. Hang wand in shower holder notch.