



# Shower Drain Installation Guide

This bathroom fixture has been carefully engineered to provide a long, trouble-free service life under normal usage. It has been factory-tested and is ready for installation. We suggest this fixture be installed by a qualified licensed plumber so the warranty will remain in affect (refer to the "General Information" insert for warranty information). We also strongly recommend tub & hardware be on site prior to rough in.

1. Insert the drain gasket into the drain flange coupling.
2. Insert the drain outlet into the metal gasket and place in the desired position. Adjust or remove the drain feet if necessary.
3. Place pea gravel over the drain flange coupling weep holes and around the perimeter to prevent mortar from filling and blocking the holes.
4. Apply mortar over the waterproof shower pan liner, starting from the drain and continuing to the wall. Using a level, create a 1-2° slope from the wall to the drain.
5. Allow the mortar to cure.
6. Once the tiling and grouting are complete, apply a thin bead of silicone sealant around the drain to fill any gaps between the drain and tile.