

## Single Post Kitchen Faucet Installation Guide

NOTE: PLEASE USE TEFLON TAPE ON ALL THREADED CONNECTIONS TO ENSURE A SEALED CONNECTION.

### Included:

- 1 pcs: Faucet
- 2 pcs: Rubber Gaskets
- 1 pair: Hot and Cold Water Supplies
- 1 pcs: Split Locking Nut w/ locking Screws

### CAUTION:

- Please confirm and inspect parts list within 48 hours
- Handle All Parts with Care
- Read All Instruction Before Installing
- Properly Test All Water Connections
- Confirm the Countertop Opening Is the Proper Diameter
- No Soldering or Heat Is Required for This Products Installation
- Do Not Over Tighten Pipe Connections

### INSTALLTION OF FAUCET:

- 1. Screw both Hot Water and Cold Water Flexible Supply Lines (Supplied With Faucet) into the pipe connections located at the bottom base of the Faucet and tighten snug.
- 2. Slip the Chrome Base Flange and Rubber Gasket over the Hot Water and Cold Water Flexible Supply Lines and 1¼" dia. Threaded Faucet Extension, alien with the bottom base of the Faucet.
- 3. Set the Faucet down onto the top of the countertop while guiding the Hot Water and Cold Water Flexible Supply Lines and Threaded Faucet Extension through the hole provided in the existing countertop. From below slip the Rubber Washer and Steel Washer onto the Threaded Faucet Extension, thread the Split Locking Nut onto the Threaded Faucet Extension and fasten tight. Tighten both Split Locking Nut Screws against the bottom of the countertop.

# Note: Before tightening the Faucet down completely, make sure Faucet is properly located and aliened with top of the countertop and sink.

4. Connect both new Hot & Cold Water <sup>3</sup>/<sub>4</sub>" NPT pipe fitting connections to existing <sup>3</sup>/<sub>4</sub>" NPT hot & cold water supplies (supplied by others) and tighten snug.