



# Sink Supply & P-Trap Installation Guide

This bathroom fixture has been carefully engineered to provide a long, trouble-free service life under normal usage. It has been factory-tested and is ready for installation.

We suggest this fixture be installed by a qualified licensed plumber so that the warranty will remain in affect (refer to the "General Information" insert for warranty information).

We also strongly recommend tub & hardware be on site prior to rough in.

- Shut off the water supply before installation
- Use Teflon tape on all threaded connections

## Supply Line Installation Instructions:

- **IMPORTANT:** THE HOUSE SUPPLY TUBES MUST EXTEND ½" beyond the finished wall.
1. Attach trim flange to wall
  2. Slide the large slip nut on to the house water supply. Female side facing out.  
**NOTE:** House water supply should be immobilize and firmly secure to prevent any movement
  3. Slide brass compression ring onto house supply tube.
  4. Attach smaller threaded end of adaptor nipple to the house supply using slip nut.
  5. Attach shut off valve stop to other end of threaded adaptor nipple.
  6. Unscrew the compression nut from the Shut off valve stop. Remove the Brass Friction Compression Ring.
  7. Slide the brass fiction ring on the supply tube ferrule end flat side toward the brass friction ring.
  8. Slide the 1/2" slip compression nut onto the supply tube (non ferrule end) female end down and slide it to the ferrule
  9. Place the Ferrule End Supply line into the straight stop valve and tighten the compression nut.
  10. Close the straight stop valves and briefly turn on the main water supply to check for leaks. If leakage occurs, tighten the connections with an adjustable wrench as necessary. If problems persist, contact Customer Service.
  11. Determine if you need to cut off any extra length of supply tubing. Usually the supply tube will not need to be cut and will be inserted into the sink faucet completely.
  12. Slide the ½" slip nut onto the supply tube female end toward the ceiling.
  13. Slide the cone washer on the supply tube flat side toward the brass friction ring. The cone washer will fit very tight/snug on the end of the tub.
  14. Small end of cone washer should be 2" below the end of the tube.
  15. Tighten the slip nut to the faucet
  16. Turn on water and check for leaks  
**Note:** Never cut the ferrule end of the supply tube. This ferrule connects the supply tube to the shut off value.

Cutting the crimp off the supply tube VOIDS the warranty.

## **P-Trap Installation Instructions:**

1. Remove slip nut joint and rubber washer from J-Pipe
2. Slide slip nut joint and rubber washer on to the other straight pipe toward the curved end.  
Female end facing ferrule
3. Slide the 3" flange onto the end of the straight pipe. Wide end towards wall. Be careful not to scratch drain tubing.
4. Secures End of straight pipe to house waste drain lines. Curve end pointing downward
5. Attach the short end of the J-Pipe to the slip nut joint
6. Remove slip nut joint and rubber washer from the other end of the J-Pipe and attach to sink drain tail piece. Female end facing J-Pipe. Drain tail piece need to extend 1"-2" into J-Pipe.
  - o Drain tail piece might need to be cut
7. Slide slip nut joint and rubber washer to tail piece and attached to J-Pipe.