




## Exposed Shower Set by Randolph Morris

Item #: RMHS74



No.	Part Name	Part No.	FINISH
1	Shower head	HLP-67	Y
2	Riser pipe	HL-43081-1	Y
3	Screw	HL-4602-6	Y
4	Escutcheon	HL-4602-3	Y
5	Anchor	HL-4602-5	
6	Screw	HL-4602-4	Y
7	Connect tube	HL-4330-12	Y
8	Loop	HL-2722M	Y
9	Screw	HL-1428	Y
10	Locknut	HL-3416-1	Y
11	Seal	HL-1906	
12	Wall coupler	HL-5314	Y
13	Washer	HL-1831	
14	Faucet body	HL-39BD	Y
15	Cartridge - Hot	HL-160M-32TH	Y
16	Escutcheon	HL-2003	Y
17	Handle	HL-2350	Y
18	Screw	HL-1414	Y
19	Diverter	HL-1714+1611	Y
20	Escutcheon	HL-2014	Y
21	Cartridge - Cold	HL-160M-32TC	Y
22	Washer	HL-1830	
23	Adaptor	HL-3437	Y
24	Shower head	HL-3710	Y
25	Hand held	HL-4364+5702	Y
26	Washer	HL-5002-1	
27	Hose	HL-5002	Y
28	Shower holder	HL-142	Y
29	Set screw	HL-1406-10V	
30	Allen key	HL-2310	
31	Screw	HL-1427	
32	Bracket	HL-2726	
33	Anchor	HL-1426	

All products and specifications are subject to change without notice. Randolph Morris is not responsible for typographical and/or dimensional errors. Typographical errors are subject to correction.

Note: Rough-in dimensions may vary +/- 1/2" and are subject to change. No responsibility is assumed by Randolph Morris.