Installation Guide

Clawfoot Tub Faucet with Porcelain Lever Handles
by Randolph Morris

Item #: RMC127

This bathroom fixture has been carefully engineered to provide a long, trouble-free service life under normal usage. It has been factory-tested and is ready for installation. We suggest this fixture be installed by a qualified licensed plumber so the warranty will remain in affect (refer to the "General Information" insert for warranty information). We also strongly recommend tub & hardware be on site prior to rough in.

- Shut off the water supply valves before installation
- Please use Teflon tape on all threaded connections available at your local hardware or plumbing supply
- Installations can vary depending on how previous fixtures were installed. Necessary supplies to install your faucet are not all included; however, they are available wherever plumbing supplies are sold
- Remove the lock nuts from back of faucet and insert faucet through the tub. Screw the lock nuts onto the threaded shanks and tighten
- Insert supply tubes into the shanks and tighten using supply washers & supply nuts