



# Downspout Tub Filler Installation Guide

**NOTE: PLEASE USE TEFLON TAPE ON ALL THREADED CONNECTIONS TO ENSURE A SEALED CONNECTION.**

This downspout faucet will arrive partially assembled. The water inlets have a 3 3/8" on center spread.

1. The lever handles will not be attached to the faucet body. You will need to attach these lever handles to the faucet body using the included screws.

## Free Standing Application

1. If your free standing supply lines are installed at a 3 3/8" on center spread you will connect the faucet directly to the supply lines.
2. If your free standing supply lines are installed at any spread width between 3" and 8 1/2" (but NOT 3 3/8") you will need to use swing arms (**boxed separately**).
3. Connect the male end of the swing arms to the free standing supply lines and adjust for the spread width needed. Connect the female end of the swing arms to the back of the faucet

## Tub Rim or Deck Application

1. Connect the short end of the threaded nipple from the hook ups (T500) into the bottom of the rim/deck mount couplers (**boxed separately**).
2. Insert threaded hook up nipples through rim/deck drilled faucet holes and using the included metal washers and/or locking nut washers, secure the rim/deck mount couplers to your tub.  
**\*\*\*If your application does NOT include swing arms (boxed separately) go to step 4\*\*\***
3. Attach the male end of the swing arms to the rim/deck mount couplers then attach the faucet body to the female end of the swing arms.
4. Attach the faucet body to the female end of the rim/deck mount couplers.

**DUE TO THE SOFT CURVES AND HAND CRAFTSMANSHIP OF YOUR TUB THERE MAY BE SLIGHT GAPS WHERE THE RIM/DECK MOUNT COUPLERS SIT ON THE RIM OF YOUR TUB. IF YOU CHOOSE, YOU CAN SEAL THESE GAPS WITH CLEAR SILICONE.**

## Bathroom Wall Mount Application

1. Your supply lines coming out of the bathroom wall will need to be at the same measurement on center as the water inlets of the faucet that you have purchased. Otherwise, you will need to use swing arms (**boxed separately**).
2. Have your plumber connect the BATHROOM TUB WALL mount couplers (**boxed separately**) directly to your house water supply lines in the bathroom wall.  
**\*\*\*If your application does NOT include swing arms go to step 4\*\*\***
3. Attach the male end of the swing arms to the bathroom wall mount couplers then attach the faucet body to the female end of the swing arms.
4. Attach faucet body to bathroom wall mount couplers.

## Tub Wall Mount Application

1. If your application includes swing arms (**boxed separately**) connect the short end of the threaded nipple from the hook ups (T7550) into the wall side of the tub wall swing arms and using the included metal washers and/or the locking nut washers, secure the swing arms to your tub wall.  
**\*\*\* If your application does NOT include swing arms go to step 2\*\*\***
2. Insert threaded hook up nipples through tub wall drilled faucet holes and using the included metal washers and/or locking bolt washers, secure tub wall mount couplers or tub wall swing arms to your tub.
3. Attach the faucet body to the female end of the tub wall mount couplers or tub wall swing arms using the flat rubber washer.

**DUE TO THE SOFT CURVES AND HAND CRAFTSMANSHIP OF YOUR TUB THERE MAY BE SLIGHT GAPS WHERE THE TUB WALL MOUNT COUPLERS SIT ON THE WALL OF YOUR TUB. IF YOU CHOOSE, YOU CAN SEAL THESE GAPS WITH CLEAR SILICONE.**



# Part 144B Installation Guide

**NOTE: PLEASE USE TEFLON TAPE ON ALL THREADED CONNECTIONS TO ENSURE A SEALED CONNECTION.**

1. Remove the faucet riser nut (F-1) and the faucet riser cone washer (F-2) from top of tub faucet.
2. Connect hand shower faucet cradle (CK-10) to top of tub faucet (be sure to use the flat washer CK-11).
3. Connect hand shower hose (CK-3) to hand shower faucet cradle (CK-10) (be sure to use the flat washer CK-4).
4. Connect hand shower hose (CK-3) to hand shower handle (CK-2) (be sure to use the flat washer CK-4).
5. Connect the hand shower head (CK-1) to the hand shower handle (CK-2).

\*\*\*Keep the large slip nut and large cone washer in a safe place in case you decide to add a shower enclosure system in the future.\*\*\*